## Flat Handle Installation Kit

For use with the Tornado transit case and wheeled cart (P/N 71085).





If you have this type handle, you will have to remove this and convert to the 38371 handle kit.



38371 handle kit installed. If you have this version, you do not have to use the conversion kit

