

HOW TO INSTALL THE ACCESSORY MOUNT ON YOUR BLOCK



PULL THE COTTER PIN OUT
OF THE BLOCK UNTIL IT
STOPS

PLACE THE MOUNT IN THE
SLOT

TAP THE COTTER PIN BACK
INTO THE BLOCK



GMP • 3111 OLD LINCOLN HWY • TREVOSE PA 19053

WWW.GMPTOOLS.COM • 215-357-5500