

How to Re-Zero your GMP C Pressure Gauge (mk3) P/N 77170

- 1) Check that the gauge is no longer under pressure before step #2.
- 2) Remove the Bezel that holds the lens from the case by hand turning it counter clock-wise until the lip on the Bezel meets the Groove on the case. Once this is lined up pull on the Bezel to remove it from the case.
- 3) At the bottom half of the dial locate the small hole. Using a screwdriver turn the screw located inside this hole in the direction needed to move the pointer. This will re-zero the Gauge. Re-install the Bezel and Lens.

NOTE: Check the air hose to make sure it is connected to the gauge tightly. The air hose connection should not swivel or spin from the pressure gauge. There should be no leaks.

Warning: Incorrect use of this instrument could cause damage and injury. The user must ensure that this instrument is used in such a way that pressure related hazards are eliminated.

Do not expose this instrument to excessive pressure (above 12 PSI).



General Machine Products Co. 3111 Old Lincoln Highway Trevose, PA 19053-4996 USA
Tel: +1.215.357.5500 Fax: +1.215.357.6216 Email: info@GMPtools.com 5/5/2006